Instruction for use for reflex glass indicator

162

Operation

The role of the reflex glass indicator is to show the height of fluid remaining in capacity or circuit. The fluid flows in the *upper box* **58** under the *refractive glass* **53**. This *refractive glass* **53** is maintained by the *lower box* **59** and is sealed by the *seals* **45**.

Ref. 162